BIOMETRIC DEVICE INSTALLATION GUIDELINE



USER MANUAL Version (1.0)

Table of Contents

Page No.

1. Hardware & Software Requirement

| 1.1) | Hardware Requirements | 3 |
|------|-----------------------|---|
| 1.2) | Software Requirements | 3 |

2. Installation Instructions

| 2.1) | Steps for installing biometric device driver | 5 |
|------|--|---|
| 2.2) | Steps for installing biometric device setup | 9 |

3. Operating Instructions

| 3.1) | Register Beneficiary | 11 |
|------|-------------------------------|----|
| 3.2) | Update Registered Beneficiary | 15 |
| 3.3) | Attendance | 17 |

1) Hardware & Software Requirement

1.1) Hardware Requirements

For the proper functioning of the biometric device, bellow hardware requirements must be fulfilled at the client side:

• **Biometric Device:** Use the latest biometric device. In our case we are using *NITGEN* biometric device (Model: HFDU08).

1.2) Software Requirements

• **Driver of Biometric Device:** Driver of Biometric device can be downloaded from the NULM website (<u>http://nulm.gov.in</u>)

Click on the link (others -> Download Driver for Biometric Device)



• Setup of Biometric Device: Setup of Biometric device also can be downloaded from the NULM website (<u>http://nulm.gov.in</u>)

Click on the link (others -> Download Setup for Biometric Device)



2) Installation Instructions

2.1) Steps for installing biometric device driver

Step 1. Your downloaded file Name would be (Biometric_Device_Driver_v3.12.zip). Unzip file by right click on the zip folder.

| 🔾 🗢 🚺 🕨 sanjeev 🕨 Dov | vnloads 🕨 | _ | Acres 1 |
|-----------------------|---------------------------|----------|---|
| Organize 👻 🔚 Open 👻 | Share with 👻 E-mail Burn | New fol | der |
| 🔆 Favorites | Biometric Device Driver_v | 3.12.zip | |
| 🥅 Desktop | | | Open |
| 🐌 Downloads | | | Extract files |
| 🕮 Recent Places | | | Extract Here |
| | | | Extract to Biometric Device Driver_v3.12\ |
| 🥽 Libraries | | | Scan with OfficeScan Client |
| Documents | | | Open with |
| J Music | | | |
| Pictures | | | Share with |
| Mideos Videos | | 9 | WinZip • |
| | | | Restore previous versions |
| Computer | | | Send to + |
| 🏭 OS (C:) | | | C-4 |
| 👝 Local Disk (D:) | | | Cut |
| HP_RECOVERY (E:) | | | Сору |
| • • • • | | | Create shortcut |
| Network | | | Delete |
| | | | Rename |
| | | | Descention |

Step 2. Please unplug the biometric device from USB port if already connected.

Step 3. Now, Open Setup.exe file.

Select appropriate model no from the list. In our case we have selected

Install

(**USB eNBioScan-c1 (HFDU08**) and finally click on button.





Step 5. When setup will ask to plug in device to USB then only plug in.

Please wait for a movement for the message (**Please connect the device**) is to appear on thescreen. Once the message is appeared (**Please connect the device**), please connect the biometric device in the USB port. You should not click on the button

Elug in later. After connecting biometric device in USB port you will get the **finish** button. Press the finish button to complete the installation.



Step 6. Plug in biometric device like this:-



Step 6. Once it is installed successfully. Finally click on

button.

Finish

| NITGEN USB Device Driver | | 0 | |
|--------------------------------------|---|--------------------------------|--|
| Setup Wizard Com | plete | JOO NITGEN | |
| Total Biometric Solution Provider | Device : USB eNBioScan-C1 (HFDU08) The Setup Wizard has successfully instal wizard. | Click on Finish Button. | |
| | | Finish | |

Steps to check whether the biometric driver is installed or not.

Step 7. To check whether driver is installed successfully or not follow the bellow instruction:-

Go to Start >> run and type **NFD** and then press enter. This will open device diagnostic utility. Under Device tab click on **device scan** button, click **init** button then place finger on sensor and click capture. Just check if image appear on left window or not. If appeared that means drivers installed successfully.

| 📼 Run | | × |
|--|---|---|
| Type the name of a resource, and Winds Open: NFD | program, folder, document, or Inte ows will open it for you. | rnet T |
| ОК | Cancel <u>B</u> rows | Step 7.1. Click on Device Tab. |
| NITGEN Fingerprint Device Diagnostic Utility DEVICE Test device driver FP Quality Check | Ni Device @ General @ Ard | Step 7.2. Click on Device Scan Button |
| | Capture Stop Save | Step 7.3. Click on Init button |
| CAPTURE | Success : 0 Option Continuous Capture | Step 7.4 . Place the finger on the biometric |
| | Step 7.5. If the finger print image is | sensor and click on capture button. |
| Success to Initialize | means drivers installed successfully. | |

2.2) Steps for installing biometric device setup

Step 1. Your downloaded file Name would be (Biometric_Device_Setup_v4.861_x86.zip). Unzip file by right click on the zip folder.



Step 2. Now, open the folder and click on Setup.exe file and follow the instruction.

| Favorites Name Desktop data1.cab Downloads data1.hdr Recent Places data2.cab Libraries alayout.bin Documents License_Eng.kt Documents License_Kors.kt Pictures readme.bt Pictures serial Key.bt Computer setup.ini | | Date mo 24-05-2 24-05-2 06-04-2 24-05-2 19-08-2 19-08-2 04-07-2 14-01-2 | 012 PM 05: 012 PM 05: 012 PM 05: 012 PM 05: 005 PM 06: 012 PM 05: 012 PM 05: 015 AM 10 005 AM 10 NITGEN eNE Prenarin | Type WinRAR archive HDR File WinRAR archive VLC media file (.bi. Text Document ESP SDK Professional | Size 784 KB 120 KB 46,555 KB 531 KB 1 KB 1 KB 1 KB 1 KR - InstallShield Wizard | |
|--|---|---|--|--|---|-----|
| ■ Desktop [™] data1.cab [™] data1.hdr [™] data2.cab | : | 24-05-2 24-05-2 24-05-2 06-04-2 24-05-2 19-08-2 19-08-2 04-07-2 14-01-2 | 012 PM 05: 012 PM 05: 012 PM 05: 005 PM 06: 012 PM 05: 012 PM 05: 005 AM 10 NITGEN eNE Prenarin | WinRAR archive HDR File WinRAR archive WLC media file (.bi. Text Document Text Document BSP SDK Professional | 784 KB 120 KB 46,555 KB 531 KB 1 KB 1 KB 1 KB 1 KR - InstallShield Wizard | |
| Downloads data1.hdr data1.hdr data2.cab | : | 24-05-2 24-05-2 24-05-2 19-08-2 19-08-2 04-07-2 14-01-2 | 012 PM 05: 012 PM 05: 005 PM 06: 012 PM 05: 012 PM 05: 005 AM 10 NITGEN eNE Prenation | HDR File WinRAR archive WinRAR archive VLC media file (.bi. Text Document Text Document BSP SDK Professional | 120 KB 46,555 KB 531 KB 1 KB 1 KB 1 KR - InstallShield Wizard | |
| Recent Places adta2.cab Libraries alayout.bin Documents License_Eng.btt Music License_Kors.bt Pictures readme.bt Pictures serial Key.bt Computer setup.ini G S (C) setup.ini | : | 24-05-2 06-04-2 24-05-2 19-08-2 19-08-2 04-07-2 14-01-2 | 012 PM 05: 005 PM 06: 012 PM 05: 005 AM 10 NITGEN eNE Prenation | WinRAR archive WinRAR archive VLC media file (.bi. Text Document Text Document BSP SDK Professional | 46,555 KB 531 KB 1 KB 1 KB 1 KR - InstallShield Wizard | |
| ■ engine32.cab ■ Libraries ▲ layout.bin ■ Documents □ License_Eng.bt ■ Music □ License_Kor.bt ■ Pictures □ readme.bt ■ Videos □ serial Key.bt ■ Computer □ setup.ini ▲ OS (Cs) ■ setup.ini | : | 06-04-2 24-05-2 19-08-2 19-08-2 04-07-2 14-01-2 | 005 PM 06: 012 PM 05: 005 AM 10 005 AM 10 NITGEN eNE | WinRAR archive VLC media file (.bi. Text Document Text Document BSP SDK Professional | 531 KB 1 KB 1 KB 1 KB - InstallShield Wizard | |
| ↓ Ibranies ▲ Iayout.bin ▶ Documents ↓ License_Eng.bt ♪ Music ↓ License_Kor.ht ■ Pictures □ readme.bt ■ Videos □ serial Key.bt ■ Computer □ setup.ini ▲ OS (C:) ● setup.ini | : | 24-05-2 19-08-2 19-08-2 04-07-2 14-01-2 | 012 PM 05: 005 AM 10 005 AM 10 NITGEN eNE | VLC media file (.bi. Text Document Text Document BSP SDK Professional | 1 KB 1 KB 1 KB - InstallShield Wizard | |
| Documents License_Eng.bt Music License_Kor.bt Pictures readme.bt Videos serial Key.bt Setup.idt setup.idt G OS (C:) setup.ini | | 19-08-2 19-08-2 04-07-2 14-01-2 | 005 AM 10 005 AM 10 NITGEN eNE | Text Document Text Document BSP SDK Professional | 1 KB 1 KR - InstallShield Wizard | |
| Music License_Kor.bt Fictures readme.bt Videos serial Key.bt Setup.exe setup.ini | | 19-08-2 04-07-2 14-01-2 | NITGEN eNE | Text Document BSP SDK Professional | 1 KB - InstallShield Wizard | |
| Pictures readme.btt Videos serial Key.btt Serial Key.btt setup.exe Computer setup.ibt So (C:) setup.ini | | 04-07-2 | Preparine | BSP SDK Professional | - InstallShield Wizard | |
| Videos serial Key.btt Computer setup.ibt So (Ci) setup.ini | | 14-01-2 | Preparine | | | |
| Computer setup.ibt | | 05.04.0 | | g Setup | | 100 |
| Computer Setup.ibt Setup.ini | | 00-04-2 | Please v | wait while the InstallShie | eld Wizard prepares the setup. | |
| 🕌 OS (C:) 💿 setup.ini | | 24-05-2 | | | | |
| | | 24-05-2 | 20 NITGEN eNBSP SDK Professional Setup is preparing the InstallShield Wiz 20 you through the rest of the setup process. Please wait. | | التربية والمتعادين المحصولان والماحية | |
| 👝 Local Disk (D:) | | 24-05-2 | | | onielu wizalu, which will | |
| HP_RECOVERY (E:) | | | | | | |
| | | | | | | |
| Network | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |

Step 3. Finally click on Finish button



3.) Operating Instructions

3.1) Register Beneficiary

Note:- Biometric device will work only on Internet explorer (version above 8.0)

Step 1. Open the NULM website (<u>http://NULM.gov.in</u>) in Internet explorer.

Step 2. Login with your training centre user ID and click on the menu:-

(Training-> Biometric Attendance-> Register Beneficiary)

| | Nation Ministry Governme | 1al UI 7 of Hou ent of Ind | rban Li Ising and | iveli l Urba | 100d 1 Pove | ls Mi erty A | ission (NULM) Ileviation | | |
|--------------------|--------------------------------|---|--|---|--|-----------------|-----------------------------|---------------------------|-----------|
| State Name : Harya | na | | | | | | ULB Name : Gurgaon | You are Login as : testto | (Log Out) |
| Home Batch | Beneficiaries | Training Biometric A Attendance Closing of Ti Forwarding to CA for As Genrate Let | Placement ttendance raining the beneficiaries sessment ter for CA | Report Register Update I Beneficia Attendar | Help Beneficiary Registered Inv | , Admin | | | |
| | | | | | | | Ministry of HUPA | | |

Step 3. A message on the browser will appear automatically. Please press

| Allow | • | button on the message. (NITGEN'S NBioBSP SDK Type Library). |
|-------|---|--|
| | - | button on the message: (111 GE11 B 11 Diobbit SDIX 1 ype Elotary). |

| Natio | nal Urban Livelihoods Missi y of Housing and Urban Poverty Allev tent of India | ion (NULM) iation | | |
|---------------------------|--|--|------------------------|-----------------------------------|
| itate Name : Haryana | | ULB Name : Gurgaon | | You are Login as : testtc (Log Ou |
| Home Batch Beneficiaries | Training Placement Report Help Admin | | | |
| Registration for biometri | c Attendance | | | |
| | Select Training : Select Training | Y | Show | |
| | | | Click | on Allow. |
| | | Ministry of HUPA | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | This webpage wants to run the following add-on: 'NITGEN's NBioBS What's the risk? | P SDK Type Library' from 'NITGEN <u>C</u> OMPANY Co., Ltd. (unverified | d publisher)'. Allow 🔻 | × |
| 🗃 🖸 🗿 🖡 | 🔰 🧔 🔕 🖉 🐰 | 10000 | | 4 % 4 🛯 k |

| Step 4. S | elect training | and click on | Show | button. | |
|------------------------------|---|---|--|------------|-------------------------------------|
| स्थायेत अल्ल | National Urban I Ministry of Housing an Government of India | L <mark>ivelihoods Missio</mark> d Urban Poverty Alleviat | n (NULM) ion | | |
| State Name : Haryar | la | | ULB Name : Gurgaon | | You are Login as : testtc (Log Out) |
| Home Batch Registration f | Beneficiaries Training Placement | Report Help Admin Select Training : Basic of Servicing (Servicing | 0 Dec 2014 - 26 Feb 2015) - (7:30 - 9: | 15) V Show | |
| | | | Ministry of HUPA | | |

Step 5. Click on **Register** button to register beneficiary on the biometric

attendance.

| Name : Haryana | | | | ULB Name : 0 | Gurgaon | | button to | register |
|---------------------|--------------------|--------------------------------|--|-------------------|-----------------------|-----------------------|-----------|----------|
| ome Batch Bene | ficiaries Training | Placement Report | Help Admin | | | | beneficia | v |
| Registration for bi | iometric Attendan | select Trainin Training Nar | g : Select Training me : Basic of Servicing (30 | Dec 2014 - 26 Feb | 2015) - (7:30 - 9:15) | ∽ Show | | |
| | S.No. | Name | Beneficiary Code | DOB | Voter Card No | Register Finger Print | Image | |
| | 1 | Ashok Yadav | BEN06041700079 | 24/03/1984 | GVK1859626 | Register | | |
| | 2 | Krishan Kumar | BEN06041700076 | 02/02/1987 | XFD0821892 | Register | | |
| | 3 | Bikash Singh | BEN06041700080 | 02/03/1991 | LBT1381581 | Register | | |
| | 4 | Hemant Kumar Singh | BEN06041700077 | 18/03/1987 | FMY3902608 | Register | | |
| | 5 | Goutam Som | BEN06041700078 | 02/02/1987 | IPS1852846 | Register | | |

Step 6. A new window will be open. Click on **NEXT** button.



Step 7. Click on the blue color **•** associated with the fingers.

| National Urban Livelihoods M Ministry of Housing and Urban Poverty Government of India | Iission (NULM) Alleviation |] |
|--|--|--|
| State Name : Haryana Tome Back Beerfdaires Training Placement Report Help A Registration for biometric Attendance Select Training i: Stele Training Name : Base Bace Back Back Back Back Back Back Back Back | Fingerprint Registration STEP1 | You are Login as : testic (Log Out) Show Register Finite Image |
| Click on the blue color associated with the fingers | Contract the finger you with the enrolity clicking ence on the corresponding tingurity: Contract (Contract of the Contract of the Co | Register San Register Register Register |
| | Ministry of HUPA | ويعتنيها |

Step 8. Now place your finger (twice) on the sensor of biometric device.

- a) Place your finger on the sensor and remove it.
- **b**) Place same finger on the sensor to confirm.



| Hume : Haryana | | | You are Login as : testt | c (I |
|------------------------|---|---|-----------------------------|------|
| lome Batch Beneficiari | ies Training Placement Report H | Fingerprint Registration STEP2 | | |
| Registration for biome | tric Attendance Select Training Training Name | Place your finger on the sensor again | Show | |
| | S.No. Name 1 Ashok Yadav | 4 1at Scan > | Register Finger Print Image | |
| | 2 Krishan Kumar | This second scan is used to confirm the first scan. | Register | |
| | 3 Bikash Singh | S ADJUST SACK S CANCEL | Register | |
| | 4 Hemant Kumar Singh | | Register | |



| te Name : Haryana Home Batch Beneficiari | ies Training Placement Rep | Fingerprint Registration | STEP1 | 2 | | | You are Login as : testto | (Lo |
|---|--|--|---|------------------------------------|---|-------|---------------------------|-----|
| Registration for biome | stric Attendance Select Trai 5.No. Name 1 Ashok Yadav 2 Krishan Kumar | Select attendate finger to enc Select attendate finger to enc corresponding fingeritar Select attendate finger to register | of by clicking once on the ton, click "MEXT" | • 9:15) ard No 19626 1892 | Show Register Finger Print Register Register | Image | | |
| | 3 Biskash Singh 4 Hemant Kumar Sin | | Die NITGEN Biemetric solutions | 1381 | Register | | | |

Step 10. Finally click on **FINISH** button to success registration.

| e Name : Haryana | ining Discoment Ra | Fingerprint Registration STEP3 | | | Yo | u are Login as : testtc | (Log (|
|---------------------------------|------------------------------|--|------------------------------|--------------------------------|-------|-------------------------|--------|
| Registration for biometric Atte | andance | Fingerprint Registration Successfully Completed | | | | | |
| 2 | Select Trai 5.No. Name | MAR. SMA | - 9:15) ard No | Show Register Finger Print | Image | | |
| 1 | Ashok Yadav | To complete fingerprint registration, click "FINIS | 59626 | Register | | | |
| 3 | Bikash Singh | 💿 BACK 💿 FINISH 🛞 I | CANCEL 1581 | Register | | | |
| 4 | 4 Hemant Kumar Sin | | TGEN tric solutions | Register | | | |
| 4 | Hemant Kumar Sin | | Increase and a second second | Register | | | |

Step 11. Once the registration is successed, a message will be popup

(Beneficiary registered successfully).

| fame : Haryana ULB Name : Gurgaon | | | | | | | | | |
|-----------------------------------|-------------|------------------|------------------|--|-------------------------|--|--|--|--|
| ne Batch Beneficiaries | Training | Placement Report | Help Admin | | | | | | |
| egistration for biometrie | c Attendand | e . | | | | | | | |
| | | Select Train | ning : Select Tr | ning 🗸 | Show | | | | |
| | | Training I | Name : Basic of | ervicing (30 Dec 2014 - 26 Feb 2015) - (7:30 - 9:15) | | | | | |
| | S.No. | Name | Benefici | Aessage from webpage Regis | ster Finger Print Image | | | | |
| | 1 | Ashok Yadav | BEN060 | 4 | | | | | |
| | | | DED 10 CO | Beneficiary registered successfully! | | | | | |
| | 2 | Krishan Kumar | BEN060 | | Register | | | | |
| | | | | OK | | | | | |

3.2) Update Beneficiary

Step 1. To update / change the registered finger of beneficiary, click on the following menu:-

(Training-> Biometric Attendance-> Update Registered Beneficiary)

| THE SE | Nation Ministry Governm | nal U y of Ho ent of In | rban L using and ^{dia} | iveli l I Urba | hood n Pove | s Mi rty Al | eviation | |
|--------------------|-------------------------------|--|--|---|---|----------------|--------------------|-------------------------------------|
| State Name : Harya | ina | | | | | | ULB Name : Gurgaon | You are Login as : testtc (Log Out) |
| Home Batch | Beneficiaries | Training Biometric A Attendance Closing of 7 Forwarding to CA for A Genrate Le | Placement Attendance | Report Register Update Benefici Attenda | Help Beneficiary Registered ary nce | Admin | | |
| | | | | | | | Ministry of HUPA | |
| | | | | | | | Show | |



| National Un Ministry of Hou Government of Inc | rban Livelihoods Mission (NULM) Ising and Urban Poverty Alleviation Ia | |
|--|--|-------------------------------------|
| State Name : Haryana | ULB Name : Gurgaon | You are Login as : testtc (Log Out) |
| Home Batch Beneficiaries Training Update Registered Beneficiary | Placement Report Help Admin Select Training : Select Training | |



| भूमि संयम्ब संयम्ब | National Urban Livelihoods Mission (NULM) Ministry of Housing and Urban Poverty Alleviation Government of India | |
|----------------------------|---|-------------------------------------|
| State Name : Harya | na ULB Name : Gurgaon | You are Login as : testtc (Log Out) |
| Home Batch Update Regis | Beneficiaries Training Placement Report Help Admin tared Beneficiary Select Training : Select Training Select Training Show Training Name : Basic of Servicing (30 Dec 2014 - 26 Feb 2015) - (7:30 - 9:15) Show | |
| | S.No. Name Beneficiary Code DOB Voter Card No Register Finger Frint Image 1 Ashok Yadav BEN06041700079 24/03/1984 GVK1859626 Update | |
| Clic | k on Update button | |

Step 4. It will ask you to enter the reason for changing the finger. Please fill the reason and click on ok button.

| स्वमेव काल | National Urban Livelihoods Mission (NULM) Ministry of Housing and Urban Poverty Alleviation Government of India | | |
|--------------------|--|---------------------------|-----------|
| State Name : Harya | na ULB Name : Gurgaon | You are Login as : testtc | (Log Out) |
| Home Batch | Beneficiary Select Training Placement Report Help Admin Select Training : Select Training V Show Training Name : Basic of Servicing (30 Dec 2014 - 26 Feb 2015) - (7:30 - 9:15) Show | | |
| | S.No. Name Beneficiary Code DOB Voter Card No Register Finger Print Image 1 Asho Soipt Prompt: OK Update Update Please enter reason for updation Caroel Fingure Cut Update | | |
| Enter the | actual reason for changing the finger and then click on ok bu | tton | \neg |

Step 5. Follow the same instruction of finger registration as described above

(Page No: 12)

| National Urban Livelihoods M Ministry of Housing and Urban Poverty Government of India | Aission (NULM) Alleviation |] | |
|---|--|-----------------------------|-------------------------------------|
| State Name : Haryana | | | You are Login as : testtc (Log Out) |
| Hone Batch Beneficiaries Training Placement Report Help A Update Registered Beneficiary Select Training Name : Basi | Total Biometric Solutions Provider | Show | |
| S.No. Name Beneficiary C 1 Aubok Yadav BEN06041700 | Show this window next time. Circk "NEXt" to begin. | Register Finger Print Image | |
| Click on Next Button | NEXT (B) CANCEL | - | |
| and follow the same | | | |
| instruction of finger | JOO NITGEN Vionetric solutions | | |
| registration. | | | |

3.3) Attendance through biometric device

Step 1. To make attendance through biometric device click on the following menu:-

(Training-> Biometric Attendance-> Attendance)

| ATTAC AND | Nation Ministry Governme | nal U1 7 of Hou ent of Ind | rban L Ising and Ia | ivelil Urbai | hood n Pove | ls Mi erty Al | ssion (NULM) leviation | |
|--------------------|--------------------------------|----------------------------------|-------------------------------|----------------------------------|----------------|------------------|---------------------------|-------------------------------------|
| State Name : Harya | na | | | | | | ULB Name : Gurgaon | You are Login as : testtc (Log Out) |
| Home Batch | Beneficiaries | Training | Placement | Report | Help | Admin | | |
| | | Biometric Attendance | | Register Beneficiary | | | | |
| | | Attendance | nining | Update Registered Beneficiary | | | | |
| | | Forwarding to CA for As | the beneficiaries sessment | Attendar | Attendance | | | |
| | | Genrate Let | ter for CA | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | Ministry of HUPA | |

Step 2. Select training and presence for (Start / End) and click on Show button



Step 3. Click on **button** to make attendance as present.

| ATTACK AND | National Urban Ministry of Housing a Government of India | Livelihoods nd Urban Povert | Mission (N y Alleviation | ULM) | | Click on Red Button to make attendance. Place your |
|---------------------------|--|--|---|--------------------------|-----------------------------|---|
| State Name : Haryan | ia | | ULE | 8 Name : Gurç | jaon | registered finger on the |
| Home Batch Biometric Atte | Beneticiaries Training Placemen | t Report Help A | dmin | | | sensor of biometric device. |
| | Sei | ect Training : Select Trai Presence : Start raining Name : Basic of Se | ning End rvicing (30 Dec 2014 - 2 | Show 6 Feb 2015) - (7 | Cancel | |
| | s.n 1 | o. Name Ashok Yadav | Beneficiary Code BEN06041700079 | DOB 24/03/1984 | Voter Card No GVK1859626 | Make Pr sence Image |
| | 2 | Krishan Kumar | BEN06041700076 | 02/02/1987 | XFD0821892 | |
| | 3 | Bikash Singh | BEN06041700080 | 02/03/1991 | LBT1381581 | |
| | 4 | Hemant Kumar Singh | BEN06041700077 | 18/03/1987 | FMY3902608 | |
| | 5 | Goutam Som | BEN06041700078 | 02/02/1987 | IPS1852846 | 3 |

Step 4. Once you click on this



(Attached with your system) will start glow.



Step 5. Now place your registered finger on the sensor of biometric device like this:-



Step 6. If it is success, then a message will be popup (Attendance made successfully).

| ate Name : Haryana | ULB Name : Gurgaon | You are Login as : testtc | (Log Ou |
|-----------------------------------|--|---------------------------|---------|
| Home Batch Beneficiaries Training | Placement Report Help Admin | | |
| Biometric Attendance | Folio Tudolan (Folio Tudolan | | |
| | Presence : @ Part C Frid | | |
| | Training Name : Basic of Servicing (30 Dec 2014 - 26 Feb 2015) - (7:30 - 9:15) | | |
| | S.No. Name and No Make Presence Image | | |
| | 1 Ashok Yadav 🔥 Attendance Made Successfully. 9626 🧭 | | |
| | 2 Krithan Kumar ОК 1592 🚱 | | |
| | 3 Bikash Singh BEN06041700080 02.03/1991 LBT1381581 | | |
| | 4 Hemant Kumar Singh BEN06041700077 18/03/1987 FMY3902608 🚱 | | |
| | 5 Goutam Som BEN06041700078 02/02/1987 IPS1852846 🚱 🚂 | | |
| | | | |
| | Ministry of HUPA | | |